# Advanced

## Direct connection for Windows

- dhcp_server_for_windows
- direct_connection

## File Tag Encoding and Display Issues

https://kb.roonlabs.com/FAQ:Some_characters_are_not_displaying_properly

## Re-burning SD Card

Only for sMS-200, to initialize whole system.

- burn_sdcard_image

## Installing Eunhasu_x86 for sMS-1000SQ

Only for sMS-1000SQ, to initialize whole system.

- Installing_Eunhasu_x86

## IckStream in LMS (not supported since May 2019)

- how_to_install_ickstream_app_in_lms



LMS should be restart when you reboot Eunhasu because IckStream plugin could not get login information just after reboot.

From:
https://wiki.sotm-audio.com/ - **SOtM docs**

Permanent link:
**https://wiki.sotm-audio.com/doku.php?id=en:eunhasu:advanced**

Last update: **2019/07/22 05:53**